

CEILING PANEL INSTALLATION WARNING

FORM 7103

When FRP panels are used in conjunction with metal overlay grid systems, the space between the panel and the grid system may be unacceptable. This issue is highlighted with the use of smooth FRP panels as illustrated in the photos below.



Using heavy duty grids with lip and flange (pictured above), may result in a space when FRP panels are installed in the grid. (see photos below).



When FRP panels are placed in the grid, there will be a space due to the design of the grid. This space is accentuated, when using smooth panels.

FOR BEST RESULTS PLEASE USE ONLY BUTT END CEILING GRID SYSTEMS OR THE SANIGRID® II FIBERGLASS CEILING GRID SYSTEM WHEN INSTALLING FRP AS A CEILING PANEL.

Please contact Crane Composites at 1.800.435.0080 if have any further questions about ceiling grids and FRP ceiling panels.